


PhoenixCard

PhoenixCard

[Download PhoenixCard](#) MicroSD card flashing tool used to flash images generated using Allwinner Technology's source code. The tool creates bootable microSD cards and NAND flashing microSD cards.



Download:

Instructions:

CAUTION!! This tool can reimage (erase) a drive if used incorrectly. Verify the drive being flashed and

as a precaution, remove any unnessecary USB drives prior to the burn process.

1 - Launch App and select the firmware to flash to the microSD card.

2 - Select the write mode, Product creates microSD card that flashes image to module NAND and Startup creates a bootable microSD card.

3 - Insert USB/MicroSD adapter and verify USB/MicroSD adapter matches the drive letter

PhoenixCard

selected in PhoenixCard.

4 - Select burn once ready to create the MicroSD card.

Unique solution ID: #1001

Author: Robert Ings

Last update: 2014-04-04 02:41